


Made in Viet Nam

**Warning :**


- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.





73968  
1-DRAWER NIGHTSTAND

**Important Use Information:** We recommend using coasters, placemats and trivets when placing hot or cold containers on this item. It is also recommended to quickly cleanup any spills to minimize exposure to moisture. Doing so will prolong the life and look of the item for many years.

**Components and Hardware List**

<p>Glass Shelf Support</p>  <p>(A) 4 PCS.</p>	<p>Plastic</p>  <p>(B) 4 PCS.</p>	<p>Glass shelf</p>  <p>(C) 1 PC.</p>	<p>Furniture Tipping Restraint Kit</p>  <p>(D) 1 PC.</p>
--	--	---	---




LED light switch under front apron

Attention :  
USB Plug attached bottom of the Nightstand

For product and personal safety, an Anti-Tip Restraint kit has been included with this cabinet which can help to minimize the risk of the cabinet accidentally tipping forward, if used and properly installed per the kit manufacturer's instructions.


# Cascade Casual Mink 73968 - 1 Drawer Nightstand



PART LIST			
#	ITEM CODE	Description	QTY
1	HA2-3528-08-60-27-NRC-10S	CPM strip 500mm, 2700K and cable 300mm	1pc
2	VAN - LED - 6WTD - S	Mini Driver 6W	1pc
3	DLC - 400	Touch Lead L=400mm	1pc
4	VAN-USAD-1212-F-AJC	12W Adapter, Cable L=3000mm	1pc

Electronic trouble shooting tips if LED light does not turn on.

1. Inspect wiring for any signs of cut wires or loose connections.
2. To make sure all connections are securely fastened, disconnect and then reconnect all connections.
3. Press and hold reset button located on the top edge of Mini Driver for 2-3 seconds.



4. If the LED Strip Light still does not turn on, unplug the Mini Driver from Adapter, unplug the LED Strip Light from the Mini Driver, then directly connect the LED strip light connection to the Adapter.
5. If the LED Strip Light turns on, **the Mini Driver** must be replaced.