


Warning :


- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.



73969
2-DRAWER NIGHTSTAND


Important Use Information: We recommend using coasters, placemats and trivets when placing hot or cold containers on this item. It is also recommended to quickly cleanup any spills to minimize exposure to moisture. Doing so will prolong the life and look of the item for many years.

Components and Hardware List



For product and personal safety, an Anti-Tip Restraint kit has been included with this cabinet which can help to minimize the risk of the cabinet accidentally tipping forward, if used and properly installed per the kit manufacturer's instructions.


Cascade Casual Mink 73969 - 2 Drawer Nightstand



| PART LIST | | | |
|-----------|---------------------------|--|-----|
| # | ITEM CODE | Description | QTY |
| 1 | HA2-3528-08-60-27-NRC-10S | CPM strip 500mm, 2700K and cable 300mm | 1pc |
| 2 | VAN - LED - 6WTD - S | Mini Driver 6W | 1pc |
| 3 | DLC - 400 | Touch Lead L=400mm | 1pc |
| 4 | VAN-USAD-1212-F-AJC | 12W Adapter, Cable L=3000mm | 1pc |

Electronic trouble shooting tips if LED light does not turn on.

1. Inspect wiring for any signs of cut wires or loose connections.
2. To make sure all connections are securely fastened, disconnect and then reconnect all connections.
3. Press and hold reset button located on the top edge of Mini Driver for 2-3 seconds.



4. If the LED Strip Light still does not turn on, unplug the Mini Driver from Adapter, unplug the LED Strip Light from the Mini Driver, then directly connect the LED strip light connection to the Adapter.
5. If the LED Strip Light turns on, **the Mini Driver** must be replaced.